



Talisman BT-41 Hubset

Thank you for your purchase! We hope you love your new hubs and we're committed to offering the finest products at a great value to our customers. If there's anything we can do to assist, please let us know. The easiest & fastest way to reach us is by email – TalismanCycles@Gmail.com

Hub Measurements

Front

110 Total width, mm
25.5 WL, width from center to left flange
41 WR, width from center to right flange
57 dL, left flange diameter
44 dR, right flange diameter
2.5 S, spoke hole diameter
32 # of spoke holes

Rear

148 Total width, mm
36 WL, width from center to left flange
23 WR, width from center to right flange
57 dL, left flange diameter
57 dR, right flange diameter
2.5 S, spoke hole diameter
32 # of spoke holes

Compatibility

The BT-41 hubset is optimized for Shimano/SRAM 11 speed HG-splined cassettes or SRAM 11 speed XD cassettes depending on the supplied freehub. For Shimano 8-10 speed, simply use the supplied spacer. Shimano 11 speed requires no spacer.

Maintenance

The BT-41 hubset requires very little other than basic care. The one thing to keep an eye on is freehub lubrication as this will dramatically extend the life of the rear hub.

We recommend cleaning & lubricating the freehub pawls every 300 miles or at least once per year.

If your freehub begins to sound significantly LOUDER – like a clacking instead of clicking – it should be lubricated. Heavier oils work best, Phil Wood Tenacious Oil for example.



Don't use grease in place of oil, it can cause the pawls to stick & fail to engage.

This is a simple process that can be performed by any competent bike tech.

Drop us a pic of your new wheels once finished, we'd love to see what you create!